

- USE ALL (6) WELD TABS 3.
- MOUNT (2) POINTS FRONT MOUNT (4) POINTS REAR 4.
- 5. REAR MÒÚNTS CAN BE ARRANGED TO USE **EXISTING HOLES**
- DRILL FRAME TABS 21/32" FOR 5/8 6. FASTENERS; (2) BOLTS PER FRAME TAB

